

Installation Instructions -- Manual procedure for Windows XP:

=====

1. Press START, Open the Control Panel, and double-click on the "Phones and Modems" icon.
2. Press the 'Modems' tab, and then press the 'ADD' button.
3. Through a series of questions, which may be different for each Windows XP system, tell the computer that you want to select a modem from a list, and that you do NOT want Windows to search for the modem.
4. When you get to the point where you are presented with a list of modems, do NOT press "Have Disk". Instead, you MUST select the Standard 28,800 modem for a GSP-1600 or a car kit. Then press "Next", select a COM port, select "Next" again, and Windows will finish installing the modem.
5. After the modem installation is complete, simply press the "X" at the top of the installation dialog boxes so that they will close.
6. The next thing you will need to do is to create a Dial-Up Networking icon/setup using the "Standard 28800" modem. To do this, Press START, then press CONTROL PANEL, double-click on 'Network Locations', and find the Networking icon labeled "Create New Connection". Indicate to Windows that you want to create a new connection to the internet using a phone or dialup connection. For ease of future reference, you should name the connection 'Globalstar Packet'.
7. The phone number you will enter is "#777" There is no area code, so you can ignore the area code entry.
8. Directly underneath the phone number entry box, there is a check box for using 'Dialing Rules'. Make sure that this check box is NOT checked.
9. Once the connection has been defined, you will see a new icon in the Networking folder, called 'Globalstar Packet'.
10. Double-click on the Globalstar Packet icon so that the "Connect To" dialog box pops up.
11. Press the PROPERTIES button located on the lower right-hand corner of the dialog box. The first "tab" of the Properties is GENERAL.
12. Go to the NETWORKING tab and press the "settings" button just below the line which starts with "PPP". Remove the check marks from all three checkboxes and press "OK".
13. While still in the NETWORKING tab, make sure that the ONLY "Networking Components" that are selected are "Internet Protocol (TCP/IP)" and perhaps "QOS". None of the Microsoft Clients should be checked, the IPX/SPX boxes shouldn't be checked and no other items should be checked. Simply remove the check marks from the unwanted components. Do NOT remove any of them.
14. Press Okay or Close to all remaining dialog boxes till you get back to the "Connect To" screen. Press "DIAL" and you should see the display on the phone change to "Dialing PPP Data". Your configuration is now complete.